


POWER BANK USAGE INSTRUCTION

Dear Value Customer,

Thank you for purchasing RP-DC100 Professional Dual Simultaneous Battery Charger & Power Supply unit. If you want to use this unit as the POWER BANK power supply kit, you need to use a professional Battery pack attached to the one of the RP-DC100 slots (Photo A) and the supplied RPC-DC4X power cable.





RPC-DC4X Supplied Power bank Cable:

If you want to use Power Bank on any other unit that need 14.4V power supply, please use supplied RPC-DC4X cable with free isolate RED and BLACK copper wire.

RED = (+) 14.7V (Positive) BACK = (-) 14.7V (Negative)

Use a isolate two wire copper core, to solder it (mount) on inaccessible Connector that uses devices that you want to power via RP-DC100 Power Bank power option.

RP-4XF Supplied Power XLR Female connector:

If you want to power supply your Camcorder by Power Bank mod, please use supplied 4pin XLR Connector RP-4XF. Please use this connection diagram to solder 2 wire cable from free end side of RPC-DC4X Power cable to 4pin XLR RP-4XF Connector.

NOTE:

DO NOT SHORT CIRCUIT BLACK and RED isolate coper wire!

